

## *Zip Tie Domes – How to Attach Handles*

Installing handles on your Geodesic Chicken Coop makes it easier to move. Our handles are made from a 7” section of 1” PVC pipe, with holes in each end of the handle for attaching to the dome using four (4) heavy-duty zip ties. Install the handles after you attach the chicken wire to the dome, as the chicken wire keeps the handles from sliding on the strut.



Loosely attach a Zip Tie just above the blue or red tape on the strut.



Loop a second Zip Tie through the handle, and then through the Zip Tie on the strut.  
Attach the Zip Ties very loosely, leaving a lot of slack.

## *Zip Tie Domes – How to Attach Handles*



Let the handle hang down so that you can see where the bottom of the handle meets the strut.

Then loosely attach a Zip Tie around the strut near the bottom of the handle.



And finish the installation by using a second Zip Tie to secure the bottom of the handle to the Zip Tie on the strut.

If you have any questions, please call us at (931) 858-6892.